

HOW TO INSTALL T2 PRODUCTS

T2 RED - UNDER TILES

Cable installation



Attach the cable (e.g. use glue gun) on the clean floor (or on a grout mesh). Apply a layer of adhesive primer.

Filler layer



Carefully apply an even layer of filler on top of the cable. Let it cure according to instructions.

Tile installation



Spread the tile adhesive and then lay out and join the tiles. In wet areas, apply a watertight coating before the tile adhesive.

Finished floor



All passage areas, corners and angles are sealed with sanitary silicon. Allow the floor to cure completely before turning the floor heating system on.

T2 REFLECTA – UNDER TILES

Installation of plates



The Reflecta sheets may be glued to the underlying floor...

Installation of plates (screws)



...or screwed in, according to special instructions.
Note: Only T2 Reflecta adhesive can be used to stick the tiles

Installation of cable



The T2 Red heating cable is placed in the already prepared grooves of the plate. The desired heat output is determined by how closely you lay out the loops of the cable.

Installation of tiles



Tiles are placed directly on top of the Reflecta plates, according to the instructions. Approximately 24 hours after joining the sheets, you may enjoy your nice warm floor.

T2 REFLECTA – UNDER WOODEN/LAMINATED/PLASTIC FLOORS

Installation of plates



The T2 Reflecta plates are laid loosely (no need to screw or glue them) on top of the sub floor.

Installation of cable



The T2 Red heating cable is placed into the grooves. The desired heat output is determined by how closely you lay out the loops of the cable.

Installation of wooden floor



Place grey rag cardboard or foam on top of the Reflecta sheets and then lay the new wooden or laminated floor according to the instructions of the manufacturer.

Installation of plastic floor



If the new overfloor is a plastic floor covering, first lay a 6mm masonite or particle board floor on top of the grey rag cardboard or the foam, and then lay out the plastic flooring according to the manufacturers instructions.