

HOW TO INSTALL T2 PRODUCTS

T2 QUICKNET – UNDER TILES

Mat installation



Roll out the heating mat on the clean floor.
Apply a layer of adhesive primer.

Filler layer



Carefully apply an even layer of filler on top of the cable.
Let it cure according to instructions.

Tile installation



Spread the tile adhesive and then lay out and join the tiles. In wet areas, apply a watertight coating before the tile adhesive.

Finished floor



All passage areas: corners and angles are sealed with sanitary silicon. Allow the floor to cure completely before turning the floor heating system on.

T2 QuickNet Questions

When should I choose T2 QuickNet-90 and when T2 QuickNet-Plus-160?

Can the cable be shortened?

Can the cable be crossed?

Can I repair a cable break?

Laying under laminate or linoleum?

T2 QuickNet Answers

If you have a poorly insulated floor or if you want a fast heat up of the floor or a higher temperature choose T2 QuickNet-Plus-160.

No, the cable must not be separated, shortened or extended. Only the mains lead can be cut.

No, the cable must not be crossed.

The repair of T2 QuickNet is possible with a special repair kit available from local stockist.

No, T2 QuickNet may only be employed in a completely flat, enclosed material. T2Reflecta is the correct system for this application, as it is a self regulating system.