

Joining Tech Multi-strap installation guide

Multi-strap range (MS) installation instructions



1. Wrap liner around cables to determine length. Discard excess liner.



2. Wrap the steel around cable with liner clipped inside. Make sure end of steel is on buckle and cut end of liner is under buckle.



3. Place split pin through **slot hole**, until pin is equal lengths on both sides with end of steel in between pin.



4. Place brass winding nut onto pin.



5. Tighten cleat by spinning pin and folding steel. Tighten using brass winding nut and ratchet/spanner. Do not overtighten.



6. Once cleat is secure and tight around cable, hammer pin into the slot so that it is fixed and unable to move.



7. Use mole grips to splay end of pin out stopping pin from turning.



8. Finished Multi-strap should look like this.