



Feed from Metering Circuit Breaker(s)

NOTE *If the same CTs and VTs are used for the main and check meters, then it will be necessary to wire links across the bottom to link the connections. If this happens then the numbering on the outgoing side of the Wago block will also need to be changed.*

1	19.08.2015	DEV	LR	RELAY TERMINAL Nos. ADDED.
Rev	Date	Drawn	Approved	Details of revision
Customer Name:		Customer Order No:		
UK POWER NETWORKS		-		
SE Sales Order No:		SE Production Order No:	SE Quotation Order No:	
-		-	-	
Range or family:	Designed by:	Approved by:	Date:	Application note:
EFU-SHLD	DEV	GH	1.05.2013	-
Update description:				Distribution code:
-				-
Material:	As per standard or specification:			-
Heat treatment:	As per specification:			-
Surface protection:	As per specification:			-
	Scale:	Tolerancing Standard:	Units of measure:	
	NTS	-	-	
Schneider Electric				
WIRING DIAGRAM FOR EECOP2-4W METER BOX				
Number:			Revision:	Sheet:
EECOP2-4W			1	1/1
State:				ISSUED